


















Thank you for purchasing the **MODWAY TV STAND** !

Before you start, here is some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
2. Owing to the size and weight of the desk, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 60 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or instructions until you have checked all the components and hardware and the furniture is fully assembled.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
6. Please keep all pieces out of reach of children.



Hardware :


A  Ø 6 x 35 mm x 9	B  Ø 15 mm x 9	C  Ø 8 x 30 mm x 36	D  M 7 x 50 mm x 5	E  L 4 x 1
F  M 12 x 35 mm x 6	G  Ø 5 x 15 mm x 8	H  M 3.5 x 13 mm x 2	I  M 8 x 39 mm x 2	J  9 x 14 x 10 mm x 8
K  M 3.5 x 15.5 mm x 8	L  25 x 25 x 2 mm x 4	M  Ø 8 mm x 2	N  Ø 15 mm(Long) x 4	O  Ø 15 mm(Short) x 1
P  Screwdriver (Not Include) x 1				




Components:



1	Top Board	x1	2	Bottom Board	x1	3	Side Board Left	x1	4	Side Board Right	x1
5	Center Board	x1	6	Adjustable Shelf	x2	7	Leg	x2	8	Support Board 1	x2
9	Support Board 2	x2	10	Support Board 3	x1	11	Door	x1	12	Back Board	x1


STEP 1:




		
Ax5	Cx12	Px1



Hardware required. Screwdriver not included

STEP 2:



			
Bx5	Nx4	Ox1	Px1

Hardware required. Screwdriver not included




	
Dx5	Ex1

x 2

A diagram of a beam with a central section labeled '8' and two end sections labeled 'C'. The beam is shown in perspective, with a central rectangular section and two cylindrical end sections. Dashed lines connect the end sections to the central section, indicating they are part of the same assembly.


x 2



A diagram of a horizontal beam with a central point labeled 10 and two points labeled C at the ends. The beam is supported by two vertical supports, one on the left and one on the right. The beam is divided into two equal segments by the central point 10. The points C are located at the ends of the beam, directly above the supports. Dashed lines connect the points C to the beam, indicating a vertical relationship.

		
Ax4	Cx20	Px1

Page 4 of 9


STEP 5:





	
Bx2	Px1

Hardware required. Screwdriver not included



STEP 6:



	
Bx2	Px1

Hardware required. Screwdriver not included



STEP 7:



Cx4

Hardware required

STEP 8:





Fx6

Lx4

Px1

Hardware required. Screwdriver not included



STEP 9:



Gx8

Hardware required

STEP 10:





Hx2

Ix2





Hardware required

STEP 11:



Mx2

Hardware required




Jx8

Kx8

Px1

Hardware required. Screwdriver not included

STEP 13:



Assembly is completed. The TV Stand is ready to enjoy now !